



escaperoomshop.it

props & puzzle

Morse Prop WiFi v02 by escaperoomshop.it ©2025



Connection:

Place your smartphone near the device and connect it to the WiFi access point


Scan the QR code or log in manually

ssid: **escaperoomshop**

pw: **12345678**


wait a few seconds for the connection to become stable

! it is advisable that there is no WiFi nearby



Once connected, scan the QR code or browse the following address:

192.168.4.1



This page will open


(if the page does not open, check the connection again)

The page will show the saved combination of the eight switches

If the combination matches, it will display **OK**

If it doesn't match **NO**

Tap on **SETUP**



This page will open

Set the eight switches on the prop according to the desired combination, the selected ones will turn red

Enter the text you want to convert to Morse code (you can enter both lowercase and uppercase characters, it makes no difference)

Select the speed of the Morse code

Tap **SAVE** to apply your settings (you will return to the home page)



escaperoomshop.it

props & puzzle

Morse Prop WiFi v02 by escaperoomshop.it ©2025

date: AUG/2025

Power supply: 12 V dc

Operation

- ⚠ Place the prop vertically
- Connect a 12V power supply to the prop
- Set the switches correctly (the LED will turn on)
- Pull the lever down to start the message

Warnings

- use indoors only
- do not install in damp places
- do not open the box if not necessary
- do not use solvents, clean with a dry cloth

Warranty

- The items are covered by the warranty of 6 months from the date of receipt of the goods.
- Are offered repair and / or free replacement in case of malfunction, shipping costs are excluded.
- Objects are not covered by warranty due to misuse, accidental fall, contact with liquids, overvoltage or short circuit.

Contact

- escaperoomshop.it@gmail.com
- <https://www.facebook.com/escaperoomshop/>